

# How to clean Angry Birds

**General cleaning first.** You should start with thoroughly cleaning the game with a solution of soapy water. Most dish soaps are not designed to kill bacteria or viruses. This is to only remove the grease and dirt from the game. Do not pour the solution directly on the game but use a clean rag; dip, twist (to remove excessive moisture), and scrub until clean.

**Damage will occur if you directly pour liquid on your game.**

Clean the clear plastics at the front and both sides after wiping down with soapy water. **DO NOT USE ammonia based cleaners!** These cleaners will damage the plastic. We recommend a plastic cleaner like Brilliance.



## How to disinfect Angry Bird games.

**Disinfect the game.**


**Step 1:** Wipe down the control handles with a disinfectant solution. **LET AIR DRY.**




**Step 2:** Wipe down the plunger with a disinfectant solution. Don't worry about the felt at the bottom of the paddle with a disinfectant solution. **LET AIR DRY.**




**Step 3:** Wipe down the coin entry, coin reject and DBV areas with a disinfectant solution. **LET AIR DRY.**




**Step 3:** Wipe down the ticket dispensing area with a disinfectant solution. **LET AIR DRY.**



**How to make a 1 gallon of soapy water (discard after use).**



**How to make your own disinfectant.**



**\* Wear eye and hand protection when handling bleach products.**