

ICEBALL 2005 ERROR CODE SHEET
[ALL UNITS AFTER ARE05#1621]

When the game is powered up it will report an error based on what sensor is bad. It will not continue until the error has been corrected. This will only occur during power up. If a sensor becomes blocked after power up, the game will not detect this as an error.

Error 1	0K Ball Return
Error 2	1K Score Problem
Error 3	2K Score Problem
Error 4	3K Score Problem
Error 5	4K Score Problem
Error 6	10K Right Sensor Problem
Error 7	10K Left Sensor Problem
Error 8	Ball Count Problem
Error 9	Coin Disconnect
Error 10	Ticket Disconnect
Error 11	Coin Switch Stuck
Error 14	Start Button Stuck
Error 16	Ball Trough not plugged in