

When Installing a Card Reader, we want it to be up front and easy to reach. On most of our games we have two locations for a Reader Installation, placement depending on the clientele of the arcade.

A common location for the installation is on the game's blank coin door, but is not always the case.



## BEAN BAG TOSS

Because the coin door is low we came up with an alternate location for the reader.

To the left you can see we mount the reader just below the display. The wire hook up will be right below as that is where the coin door harness is. This for Embed readers for Intercard we advise to update the and put a DBV door. The Intercard reader is much bigger and heavier unit. *Intercard reader not pictured*

*When drilling into plastic use a 7/32 acrylic drill bit for screws*

*Use 1/2 acrylic drill bit for wires*

