


How to clean ICEBALL FX

General cleaning first. You should start with thoroughly cleaning the game with a solution of soapy water. Most dish soaps are not designed to kill bacteria or viruses. This is to only remove the grease and dirt from the game. Do not pour the solution directly on the game but use a clean rag; dip, twist (to remove excessive moisture), and scrub until clean.


Damage will occur if you directly pour liquid on your game.

Be sure to clean the following:

- Scrub the lanes well.
- Drop the balls directly into the soapy bucket and scrub. Start a game to capture the balls.
- Clean the start button
- Clean the ball return area



How to make a 1 gallon of soapy water (discard after use).



Clean the clear plastics that protect the playfield area but only after wiping down with soapy water. **DO NOT USE ammonia based cleaners!** These cleaners will damage the plastic. We recommend a plastic cleaner like Brilliance.

How to disinfect ICEBALL FX games.


Disinfect the game. All steps require the use of a disinfectant solution.

Step 1: Wipe down the start button.

Step 2: Wipe down the coin entry, coin reject and DBV areas.

Step 3: Wipe down the ticket dispensing area.

LET EVERYTHING AIR DRY.



Step 4: Wipe all balls and **LET AIR DRY BEFORE RETURNING TO THE GAME.**




Step 5: Wipe all areas at the front where the player could come in contact with when playing a game. Use a disinfectant solution.

LET AIR DRY BEFORE RETURNING TO THE GAME.



How to make your own disinfectant.



*** Wear eye protection when handling any bleach products.**